

# FASERFIX KS / FASERFIX SUPER

## - MAINTENANCE INFORMATION

### Maintenance information

The drainage system must be inspected at regular intervals and checked for proper functioning. If necessary, fouling of leaves, debris or vegetation must be removed from gratings, channels, trash boxes, mud buckets and drains and disposed of properly.

To ensure continued function, the inspection interval shall be selected or determined as necessary based on local conditions and relevant experience.

### **SIDE-LOCK locking system**

For FASERFIX systems, the clips of the SIDE-LOCK locking system must be checked separately for dirt during inspection and cleaned if necessary.

### **Maintenance of screw connections**

The operability of the screw fitting must be checked at regular inspection intervals. The inspection interval must be selected or, if necessary, determined on the basis of the local conditions and relevant experience. If necessary, bolts and nuts must be made passable, derusted and treated with rust inhibitor.

If inspection intervals that are too long and/or insufficient maintenance have already led to rusted screw connections, HAURATON offers corresponding repair kits including instructions on request.

Note: The information provided here represents our best knowledge and experience to date. We reserve the right to make changes as technology advances and for the purpose of continuing product development. Users of the products are responsible for checking the functions and application options of these products by consulting with qualified engineers. The mentioning of trade names does not constitute a recommendation and does not preclude the use of other products that have been tested in the same way. For further information please refer to the respective safety data sheets or application areas, e.g. for elastic sealing compounds. Any new edition of this publication renders older editions invalid. Date: 05/2021